

# Junction Box Installation Guide


## **About this guide**

This guide is valid for Agave-TH and Myrtillo series. It describes the information, installation and electrical connection of the system divided into two stacks. It will be helpful for some installation scenarios with height limitations.


This guide applies to qualified electricians. The qualified electricians have to be familiar with the product, local standards, and electric systems. The tasks described in this guide should only be performed by qualified electricians.

## System overview and ports

The below system is an example. Please determine the number of battery modules to be installed according to needs.




Myrtillo




Agave-TH

1 Junction Box














NO.	Parts
1	COM connector
2	BAT connector
3	Guided quick connector

2 Special base



NO.	Parts
1	Guided quick connector
2	BAT connector
3	COM connector

Packing List

WH- Junction Box		
		
1 × Junction Box		1 × Special Base
		
1 × Metal Bracket	1 × Locking Bracket	4 × Sheet Metal Brackets
		
8 × M5*12 Screws 1×OT5-5 Terminal	4 × Φ10*60 Expansion Bolts	4 × M4*10 screws
		
2×Positive DC Connector 2×Negative DC Connector	2×RJ45 Connector	1 × Quick Installation Guide

## Installation Steps and Electrical Connection

